## LEHI IRRIGATION COMPANY RULES AND REGULATIONS

The following rules and regulations are hereby adopted and promulgated by the Lehi Irrigation Company relating to the distribution of water by the Company and the use thereof by its stockholders:

- No stockholder of the Company shall interfere in any manner with the regulation of the Companyos dams and ditches, nor shall he take or divert to his use any water running in said ditches until and unless he is entitled thereto by virtue of his water turn.
- 2. No stockholder shall allow any ditch or lateral of the Company passing through the land of such stockholders or along a public street adjacent thereto to become clogged, filled or damaged by reason of any acts of such stockholder or his agents or employees, or as a result of the activities of his livestock. Nor shall he dump or cause or permit to be dumped or discharge into any such ditch or lateral any refuse or other material.
- No person shall insert a head gate or place a dam in any ditch or lateral except during such time as he is entitled to the water or portion thereof while water is flowing therein or likely to flow therein.
- 4. Every stockholder shall be responsible for the water taken by him from the Company ditch during the entire time of his turn and shall not allow said water to flood upon the land or property of another or upon the public right-of-way.
- 5. No stockholder shall divert water from the company ditch or lateral except at such point or points as may be allocated to him by the water superintendent or master; and in no event shall the company ditch or lateral be used as the head ditch for the general discharge of the water onto the land.
- 6. Each stockholder shall provide a suitable and sufficient head gate for diverting water from the Companys ditch or lateral at each of the points where he is entitled to take his water. Such head gate shall be in form and construction as is approved by the water superintendent or master, both as to outlet on the company ditch and the inlet to the diverting head ditch of the stockholder.
- 7. No stockholder shall exchange turns with another so as unreasonably to interfere with the usual and ordinary course of succession of water turns and the use of the water along the stream, lateral, or ditch without the approval of the water superintendent or master.
- 8. No stockholder shall change or alter the course of any Company ditch or lateral, or cover the same, without the written consent of the Board of Directors.
- 9. Each stockholder shall cooperate with the water superintendent and/or water master for the orderly, equitable, and efficient distribution of the water.
- 10. Every stockholder shall promptly report to the water superintendent any damage to any part of the companys system that might come to the attention of such stockholder or any infraction of the Rules and Regulations of the Company which might result in any damage or injury to the Company.
- 11. These Rules and Regulations shall be approved by the stockholders of the Company and shall thereafter take effect on March 1, 1959. Prior to said date the Secretary of the Company shall email, print, or cause to be printed, and mail a copy thereof to the stockholders and shall also be available for printing on our website at <a href="https://www.lehiirrigationcompany.com">www.lehiirrigationcompany.com</a>.